

		Bauform	Messbereich	Anzahl Achsen	Ausgangssignal	Speisespannung [VDC]	Temp. Bereich [°C]	Schutzart Gehäuse	Rauschen [ug/SQRT(Hz)]
	**SCA103T-D04**								
	**SCL3300-D01**	IC	± 10 - 90	3	SPI	3.0 to 3.6	-40 to 125		15 to 32
	**SCL3400-D01**	IC	± 0 - 91	2	SPI	3.0 to 3.6	-40 to 85		16
	**SCL3300-D01-PCB**	Platine	± 0 - 90	4	SPI	3.0 to 3.6	-40 to 125		
	**SCL3400-D01-PCB**	Platine	± 0 - 92	2	SPI	3.0 to 3.6	-40 to 85		16
	**SCA830-D07**	IC	± 0 - 90	1	SPI	3.0 to 3.6	-40 to 125		50
	**SCA830-D07-PCB**	Platine	± 0 - 90	1	SPI	3.0 to 3.6	-40 to 125		
	**SAS221T-D09a**	Plug&Play Module	± 0 - 90	2	2,5 V +/- 2,0V	4.75 to 5.5	-25 to + 85	IP66	10

		Bauform	Messbereich	Anzahl Achsen	Ausgangssignal	Speisespannung [VDC]	Temp. Bereich [°C]	Schutzart Gehäuse	Rauschen [ug/SQRT(Hz)]
	**ESC30**	Plug&Play Module	± 10, 20, 30, 45, 60, 80	2	10% - 90% Vin, 0.5 - 4.5 V, 4...20mA, RS-485	5V, 8 to 30, 20 to 28	-30 to 85	IP67	
	**THD2000Z**	Plug&Play Module	± 10, 20, 30, 45, 60	2	10% - 90% Vin, RS-485	5V	-30 to 85		
	**PEI-S103-1-0.6**		0.6	1	RS485, RS232, 0 - 5V,		-20 to 60		
	**PST20-01**	Plug&Play Module	± 10 - 180	1	0.5 - 4.5 V, 4...20 mA, RS232, RS485, CAN2.0B	9 to 36	-40 to 85	IP67	
	**PST20-02**	Plug&Play Module	± 10 - 180	2	0.5 - 4.5 V, 4...20 mA, RS232, RS485, CAN2.0B	9 to 36	-40 to 85	IP67	
	**PEI-S102-1**	Plug&Play Module	± 5 to 90	1	0 - 5 V, 0 - 10 V, 4...20 mA, 0...20 mA	12 to 30	-40 to 70	IP67	
	**PEI-Z245SS**	Plug&Play Module	± 45	2	TTL	5	-40 to 85	IP68	
	**PMP-20HTL**	Plug&Play Module	± 20	1	0.5 V - 4.5 V	5	-20 to 80		

		Bauform	Messbereich	Anzahl Achsen	Ausgangssignal	Speisespannung [VDC]	Temp. Bereich [°C]	Schutzart Gehäuse	Rauschen [ug/SQRT(Hz)]
	**PMP-20HTZL**	Plug&Play Module	± 20	2	0.5 V - 4.5 V	5	-20 to 80		
	**PMP-5HTZL**	Plug&Play Module	± 5	2	0.5 V - 4.5 V	5	-20 to 80		
	**PMP-30HTL**	Plug&Play Module	± 30	1	0.5 V - 4.5 V	5	-20 to 80		
	**PMP-30HTZL**	Plug&Play Module	± 30	2	0.5 V - 4.5 V	5	-20 to 80		
	**PMP-S30HT**	Platine	± 30	1	0.5 V - 4.5 V	5	-20 to 80		
	**PST141**	Plug&Play Module	± 5, 10, 15, 30, 45, 60, 90	1	0.5 - 4.5 V	9 to 36	-40 to 85	IP67	
	**PST142**	Plug&Play Module	± 5, 10, 15, 30, 45, 60, 90	2	0.5 - 4.5 V	9 to 36	-40 to 85	IP67	
	**PST151**	Plug&Play Module	± 5, 10, 15, 30, 45, 60, 90	1	4...20 mA	16 to 36	-40 to 85	IP67	

		Bauform	Messbereich	Anzahl Achsen	Ausgangssignal	Speisespannung [VDC]	Temp. Bereich [°C]	Schutzart Gehäuse	Rauschen [ug/SQRT(Hz)]
	**PMP-S5HT**	Platine	± 5	1	0.5 V - 4.5 V	5	-20 to 80		
	**PMP-5HTL**	Plug&Play Module	± 5	1	0.5 V - 4.5 V	5	-20 to 80		
	**PST152**	Plug&Play Module	± 5, 10, 15, 30, 45, 60	2	4...20 mA	16 to 36	-40 to 85	IP67	
	**PMP-S10HT**	Platine	± 10	1	0.5 V - 4.5 V	5	-20 to 80		
	**PMP-10HTL**	Plug&Play Module	± 10	1	0.5 V - 4.5 V	5	-20 to 80		
	**PMP-10HTZL**	Plug&Play Module	± 10	2	0.5 V - 4.5 V	5	-20 to 80		
	**PMP-S20HT**	Platine	± 20	1	0.5 V - 4.5 V	5	-20 to 80		
	**T7**	Plug&Play Module	± 0 - 360	1	RS232/ RS485, modbus	5.5 to 30	-10 to 70	IP68	

		Bauform	Messbereich	Anzahl Achsen	Ausgangssignal	Speisespannung [VDC]	Temp. Bereich [°C]	Schutzart Gehäuse	Rauschen [ug/SQRT(Hz)]
	**UV-00H**	Plug&Play Module	± 60	1	0.5 V - 4.5 V	5	-20 to 80		
	**UV-3HF**	Platine	± 20	1	1 V - 4 V	5	-30 to 80		
	**WR-7UHA**	Plug&Play Module	± 60	1	0.5 V - 4.5 V	5	-30 to 80		
	**WR-7UHA360**	Plug&Play Module	± 0 - 360	1	0.5 V - 4.5 V	5	-30 to 80		

Angst+Pfister
Sensors and Power

We are here for you. Addresses and Contacts.

Headquarter Switzerland:

Angst+Pfister Sensors and Power AG
Thurgauerstrasse 66
CH-8050 Zurich
Phone +41 44 877 35 00
sensorsandpower@angst-pfister.com

Office Germany:

Angst+Pfister Sensors and Power Deutschland GmbH
Edisonstraße 16
D-85716 Unterschleißheim
Phone +49 89 374 288 87 00
sensorsandpower.de@angst-pfister.com

Scan here and get an overview of personal contacts!

sensorsandpower.angst-pfister.com