		Spannung [Vr]	Strom max [Id]	RDS(on) typ	Gehäuse
	**UF4SC1200-Serie**	1200V	53A	23mOhm, 30mOhm	TO-247-4L
	**UF4C1200-Serie**	1200V	27,5A 34A	53mOhm, 70mOhm	TO-247-3L, TO-247-4L
	**UJ4C0750-Serie**	750V	21A to 120A	6 mOhm to 60 mOhm	TO-247-3L, TO-247-4L
	**AP-EVAL-UJ4C075018K4S**	750	81A	18mOhm	Evaluation Board
	**AP-EVAL-UF3SC120009K4S**	1200V	120,0A	9mOhm	Evaluation Board
	**UF3C065030K3S**	650V	85A	27 mOhm	TO-247-3L
	**UF3C120150K4S**	1200V	18,4A	150mOhm	TO-247-4L
	**UF3C120040K3S**	1200V	65,0A	35mOhm	TO-247-3L

		Spannung [Vr]	Strom max [Id]	RDS(on) typ	Gehäuse
	**UF3SC065030B7S**	650V	62,0A	27mOhm	D2PAK-7L
	**UF3SC065040B7S**	650V	47,0A	42mOhm	D2PAK-7L
	**UF3SC065080K3S**	650V	31,0A	80mOhm	TO-247-3L
	**UF3SC065007K4S**	650V	120,0A	6.7mOhm	TO-247-4L
	**UF3C065080B7S**	650V	27,0A	80mOhm	D2PAK-7L
	**UF3SC120016K4S**	1200V	107,0A	16mOhm	TO-247-4L
	**UF3SC120016K3S**	1200V	107,0A	16mOhm	TO-247-3L
	**UF3C065080T3S**	650V	31,0A	80mOhm	TO-220-3L

		Spannung [Vr]	Strom max [Id]	RDS(on) typ	Gehäuse
	**UF3SC120009K4S**	1200V	120,0A	8.6mOhm	TO-247-4L
	**UF3C065030K4S**	650V	85A	27 mOhm	TO-247-4L
	**UF3C065030T3S**	650V	85A	27 mOhm	TO-220-3L
	**UF3C065040K3S**	650V	54A	42 mOhm	TO-247-3L
	**UF3C065040K4S**	650V	54A	42 mOhm	TO-247-4L
	**UF3C065040T3S**	650V	54A	42 mOhm	TO-220-3L
	**UF3C065080K4S**	650V	31A	80 mOhm	TO-247-4L
	**UF3C120040K4S**	1200V	65A	35 mOhm	TO-247-4L

		Spannung [Vr]	Strom max [Id]	RDS(on) typ	Gehäuse
	**UF3C120080B7S**	1200V	33A	80 mOhm	D2PAK-7L
	**UF3C120080K4S**	1200V	33A	80 mOhm	TO-247-4L
	**UF3C120150B7S**	1200V	18,4A	150 mOhm	D2PAK-7L
	**UJ3C065030K3S**	650V	85A	27 mOhm	TO-247-3L
	**UJ3C065030T3S**	650V	85A	27 mOhm	TO-220-3L
	**UJ3C065080K3S**	650V	31A	80 mOhm	TO-247-3L
	**UJ3C065080T3S**	650V	31A	80 mOhm	TO-220-3L
	**UJ3C120040K3S**	1200V	65A	35 mOhm	TO-247-3L

		Spannung [Vr]	Strom max [Id]	RDS(on) typ	Gehäuse
	**UJ3C120080K3S**	1200V	33A	80 mOhm	TO-247-3L
	**UJ3C120150K3S**	1200V	18,4A	150 mOhm	TO-247-3L
	**UJ3SC120040B7S**	1200V	40A	40 mOhm	D2PAK-7L
	**UJ3C120070K3S**	1200V	34,5A	70mOhm	TO-247-3L

Angst+Pfister
Sensors and Power

We are here for you. Addresses and Contacts.

Headquarter Switzerland:

Angst+Pfister Sensors and Power AG
Thurgauerstrasse 66
CH-8050 Zurich
Phone +41 44 877 35 00
sensorsandpower@angst-pfister.com

Office Germany:

Angst+Pfister Sensors and Power Deutschland GmbH
Edisonstraße 16
D-85716 Unterschleißheim
Phone +49 89 374 288 87 00
sensorsandpower.de@angst-pfister.com

Scan here and get an overview of personal contacts!

sensorsandpower.angst-pfister.com