














		Measuring range	Pressure type	Temp. range [C°]	Switching capacity	Pressure port	Switching point	Ex certification
	903	3 to 50 mbar	Gauge	-20 to +85	6A / 250VAC, 2A / 24VDC	Tube connection, threaded connection	Fixed	No
	80A Electronic pressure switch	1 mbar to 20 bar	Gauge	-20 to +85	6A / 250VAC, 2A / 24VDC	Tube connection, threaded connection	Fixed	No
	908	4 to 1000 mbar	Differential	-10 to +80	6A / 250VAC, 2A / 24VDC	threaded connection 1/8" inner	Adjustable	No
	901.1	5 to 1000 mbar	Gauge	-40 to +130	6A / 250VAC, 2A / 24VDC	Tube connection, threaded connection	Fixed	No
	901.1-EX	5 to 1000 mbar	Gauge	-40 to +130	6A / 250VAC, 2A / 24VDC	Tube connection, threaded connection	Fixed	Yes
	901.2	-5 to -900 mbar	Vacuum	-40 to +130	6A / 250VAC, 2A / 24VDC	Tube connection, threaded connection	Fixed	No
	901.21	-5 to -900 mbar	Vacuum	-40 to +130	6A / 250VAC, 2A / 24VDC	Tube connection, threaded connection	Fixed	No
	901.2-EX	-5 to -900 mbar	Vacuum	-40 to +130	6A / 250VAC, 2A / 24VDC	Tube connection, threaded connection	Fixed	Yes

		Measuring range	Pressure type	Temp. range [C°]	Switching capacity	Pressure port	Switching point	Ex certification
	901.3	5 to 50 mbar	Differential	-40 to +130	6A / 250VAC, 2A / 24VDC	Tube connection, threaded connection	Fixed	No
	901.30-EX	5 to 50 mbar	Differential	-40 to +130	6A / 250VAC, 2A / 24VDC	Tube connection, threaded connection	Fixed	Yes
	901.41	500 to 3000 mbar	Gauge	-40 to +130	6A / 250VAC, 2A / 24VDC	Tube connection, threaded connection	Fixed	No
	901.41-EX	500 to 3000 mbar	Gauge	-40 to +130	6A / 250VAC, 2A / 24VDC	Tube connection, threaded connection	Fixed	Yes
	901.51	1 to 12 bar	Gauge	-40 to +130	6A / 250VAC, 2A / 24VDC	Threaded connection	Fixed	No
	901.51-EX	1 to 12 bar	Gauge	-40 to +130	6A / 250VAC, 2A / 24VDC	Threaded connection	Fixed	Yes
	901.6	5 to 3000 mbar	Gauge	-40 to +130	6A / 250VAC, 2A / 24VDC	Tube connection, threaded connection	Adjustable	No
	901.6-EX	5 to 3000 mbar	Gauge	-40 to +130	6A / 250VAC, 2A / 24VDC	Tube connection, threaded connection	Adjustable	Yes

		Measuring range	Pressure type	Temp. range [C°]	Switching capacity	Pressure port	Switching point	Ex certification
	901.7	-5 to -700 mbar	Vacuum	-40 to +130	6A / 250VAC, 2A / 24VDC	Tube connection, threaded connection	Adjustable	No
	901.7-EX	-5 to -700 mbar	Vacuum	-40 to +130	6A / 250VAC, 2A / 24VDC	Tube connection, threaded connection	Adjustable	Yes
	901.8	5 to 50 mbar	Differential	-40 to +130	6A / 250VAC, 2A / 24VDC	Tube connection	Adjustable	No
	901.8-EX	5 to 50 mbar	Differential	-40 to +130	6A / 250VAC, 2A / 24VDC	Tube connection	Adjustable	Yes
	901.9	1 to 12 bar	Gauge	-40 to +130	6A / 250VAC, 2A / 24VDC	Threaded connection	Adjustable	No
	901.9-EX	1 to 12 bar	Gauge	-40 to +130	6A / 250VAC, 2A / 24VDC	Threaded connection	Adjustable	Yes
	911.81	20 to 500 Pa	Gauge, Vacuum, Differential	-20 to +85	1A / 250VAC, 0.1A / 24VDC	Tube connection	Adjustable	No
	930.8	20 to 4000 Pa	Gauge, Vacuum, Differential	-20 to +85	1A / 250VAC, 0.1A / 24VDC	Tube connection	Adjustable	No

		Measuring range	Pressure type	Temp. range [C°]	Switching capacity	Pressure port	Switching point	Ex certification
	930.8-EX	20 to 4000 Pa	Gauge, Vacuum, Differential	-20 to +85	0.1A / 24VDC	Tube connection	Adjustable	Yes
	501 Niederdruckwächter/Low pressure switch	10 to 1000 mbar	Gauge	-20 to +80	2A / 250VAC	Threaded connection	Adjustable	No
	602 603 604 605 Wechsler/Changeover contact	0.2 to 300 bar	Gauge	-20 to +80	6A / 250VAC	Threaded connection	Adjustable	No
	701 702 Unterdruckwächter/Vacuum switch	-0.05 to -1 bar	Vacuum	-20 to +80	5A / 250VAC	Threaded connection	Adjustable	No
	801 803 807 809 Öffner/N.C.	0.2 to 200 bar	Gauge	-20 to +100	2A / 250VAC	Threaded connection	Adjustable	No
	802 804 808 810 Schliesser/N.O.	0.2 to 200 bar	Gauge	-20 to +100	2A / 250VAC	Threaded connection	Adjustable	No

We are here for you. Addresses and Contacts.

Headquarter Switzerland:

Angst+Pfister Sensors and Power AG
Thurgauerstrasse 66
CH-8050 Zurich
Phone +41 44 877 35 00
sensorsandpower@angst-pfister.com

Office Germany:

Angst+Pfister Sensors and Power Deutschland GmbH
Edisonstraße 16
D-85716 Unterschleißheim
Phone +49 89 374 288 87 00
sensorsandpower.de@angst-pfister.com

Scan here and get an overview of personal contacts!



sensorsandpower.angst-pfister.com