



	Moyen d'exploitation	Zone de contact	Plage de température
	SQ-UST-A1		
	SQ-UST-G1		
	SQ-PCB-3S		
	SQ-PCB-5S		
	SQ-Eval-Kit-A1		
	SQ-Eval-Kit-G1		

We are here for you. Addresses and Contacts.

Headquarter Switzerland:

Angst+Pfister Sensors and Power AG
Thurgauerstrasse 66
CH-8050 Zurich
Phone +41 44 877 35 00
sensorsandpower@angst-pfister.com

Office Germany:

Angst+Pfister Sensors and Power Deutschland GmbH
Edisonstraße 16
D-85716 Unterschleißheim
Phone +49 89 374 288 87 00
sensorsandpower.de@angst-pfister.com

Scan here and get an overview of personal contacts!



sensorsandpower.angst-pfister.com